

FREEAXEZ USA™

The Premier Low Profile Access Floor

JOB SITE TOOL LIST

EACH INSTALLER SHOULD HAVE:

- ✓ Black Magic Marker – “Sharpie”
- ✓ Razor Knife

EACH JOB SITE SHOULD HAVE:

- ✓ Chop Saw and/or Reciprocating Saw with Metal Blade
- ✓ Hammer Drill
- ✓ Hammer
- ✓ Pliers
- ✓ Camera
- ✓ Ramp Anchor Screws
Buildex Model Tapcon 3/16” x 1-1/4” (Part # 24300) or equivalent
- ✓ 3M-77 Spray Adhesive

Thanks for your efforts!

420 Keim Boulevard • Burlington, NJ 08016
Phone: 609-747-8400 / 888-747-8400 • Fax: 609-747-8600
www.freeaxe.com