

FREEAXEZ 40/70

Maintenance Instructions

Please read this sheet and follow the instructions carefully. FreeAxez USA is not liable for any product damage or personal injury caused by improper handling, installation, or use.


Wear Hand Protection

- Always wear work gloves when handling FreeAxez system components.



Avoid Moisture

- Keep water and all liquids off the components. Keep the channels and all areas under the floor free from moisture.
- In the event of a spill, remove channels (and base, if necessary), and wipe up the moisture with a dry cloth.






Avoid Excessive Loads

- Install reinforcing units before placing an item that exceeds the capacity load.
- Be careful not to exceed the load-bearing specifications.

Wiring Directions


- Channel Access: (please follow the arrows)




*Follow the reverse directions for closing

- Wiring Pathways:


- Install cables in either standard wiring channels or additional raceway under each base unit **only**.
- When installing cables, remove all channels and corners along the path of intended cable travel prior to installation.




- When installing cables, remove all channels and corners along the path of intended cable travel prior to installation.



- Use care to avoid installing cables under the load-bearing base support legs to avoid power failure or damage to cable jacketing.



- Use rubber grommets if necessary to avoid potential strain on cables against metal floor components.



- Do not pull or tug on cables during removal or repositioning. Gently lift the cables out of existing location--pulling cables can cause power failure or damage to cable jacketing.

If you have any questions, please do not hesitate to contact us:

FreeAxez USA
420 Keim Boulevard
Burlington, NJ 08016

phone: (609) 747-8400

fax: (609) 747-8600

email: info@freeaxe.com